



Suggested lines to concentrate on to determine pathway from source area to seep.

- 1500 feet long traverse
- Shorter than 1500 feet

● Location of Seeps

— May be possible in the process area to investigate the seep